


# ACCESSORIES



## ATTACHMENT

The Front Plate and Rear Exterior Velcro® provide convenient and secure ways to attach and detach various accessories to different positions, allowing for personalized customization.

Front Plate



Rear Exterior Velcro & Mounting Plate for Counterweights



## VIDEO CAMERAS

The Skull Mounting System provides mounting options for various types of video cameras. A Counterweight can be attached to the rear of the Skull Mounting System to counterbalance the weight of accessories attached to the Front Plate.

## ILLUMINATION / IFF

Skull Mounting System allows for streamlined mounting of devices such as IR illuminators, lights, and IFF devices. The Rear Exterior Velcro provides a quick way to attach and detach accessories.

## WARRANTY

The Skull Mounting System is warranted for (1) year from date of purchase against material defects and/or faulty workmanship. This warranty is in lieu of all other warranties, expressed, implied, or statutory, and is strictly limited to the terms hereof. Ops-Core specifically disclaims any warranty of merchantability or of usefulness for a particular purpose. The defective product must be returned to Ops-Core with proof of purchase and information describing the nature of the problem. It is expressly agreed that the Purchaser's sole and exclusive remedy for breach of the above warranty, for any tortious conduct of Ops-Core, or for any other cause of action, shall be the repair, replacement, or credit, at Ops-Core's discretion, of any components or parts thereof, that after examination by Ops-Core are proven to be defective. If it is determined by Ops-Core that the product's failure was due to accident, abuse, misuse, neglect, improper maintenance, or normal wear and tear, the product is not covered in this warranty. Ops-Core shall be released from all obligations under this warranty in the event repairs or modifications are made to any of the parts by persons other than its own service personnel. No agent, employee or representative of Ops-Core may bind Ops-Core to any affirmation, representation or modification of the warranty concerning the goods sold under this contract. Exclusion of Consequential Damages – Purchaser specifically understands and agrees that under no circumstances will Ops-Core be liable to Purchaser for economic, special, incidental, or consequential damages or losses of any kind whatsoever, including but not limited to, loss of anticipated profits and any other loss caused by reason of the non-operation of the goods. This exclusion is applicable to claims for breach of warranty, tortious conduct or any other cause of action against Ops-Core.

## ⚠ WARNING

The Skull Mounting System does not provide any type of protection for the head and does not offer any protection against neck, spinal, or brain injuries including those caused by rotational forces. Inspect the Skull Mounting System before each use. Make sure the adjustment dials, plastic hardware, stitching, chinstrap, and fit system components are not damaged, cracked, deformed, loose or showing signs of excessive wear. If they do, replace them or the Skull Mounting System.

[www.ops-core.com](http://www.ops-core.com)



# SKULL MOUNTING SYSTEM

## OPERATOR'S MANUAL

© OPS-CORE 2017 06-01-400 REV. B



### KIT INCLUDES:

- (1) Skull Mounting System equipped with (1) ½" Front Pad, (1) ¼" Top Pad, (1) ¼" Rear Pad, (1) ¼" Let Side Pad, (1) ¼" Right Side Pad; and additional (1) ½" Rear, (1) ½" Left Side, and (1) ½" Right Side Pads




# INTRODUCTION

## ABOUT YOUR SKULL MOUNTING SYSTEM

This manual covers the basic operating and fitting instructions for the Ops-Core Skull Mounting System. The Skull Mounting System is a multi-purpose headgear integration device that is compatible with a variety of attachments. The Three Dial Adjustment system accommodates a full range of head shapes and sizes.

## COMFORT PAD SETUP

The Skull Mounting System is designed to fit the majority of head sizes. However, some users with smaller head sizes may find the thin pads to result in a loose fit. If this occurs, replace the back and side pads with the thicker comfort pads shown in dark grey.



## COUNTERWEIGHT KIT (OPTIONAL)

If you purchased a Counterweight Kit with your Skull Mounting System kit includes (1) Small and (1) Large Counterweight with corresponding hardware.




## COUNTERWEIGHT ATTACHMENT

**NOTE: ONLY ATTACH A COUNTERWEIGHT IF YOU NEED TO COUNTERBALANCE AN ATTACHMENT AT THE FRONT OF THE Skull Mounting System.**

Align Counterweight holes to the holes on the back of the Skull Mounting System. Hold Counterweight in place and use your fingers to loosely attach a screw through the Counterweight and Skull Mounting System. Repeat for the remaining 2 holes.



Finish by using a screwdriver to tighten all 3 screws from the outside of the Counterweight, making sure the Counterweight is securely fastened to the Skull Mounting System.



# FIT & ADJUSTMENT


## 1 SKULL MOUNTING SYSTEM SETUP

- Turn Adjustment Dials counter-clockwise (left) to make the Skull Mounting System is fully open.
- Place open Skull Mounting System on your head so that the Front Plate is centered over the bridge of your nose. Begin adjustment by firmly pressing down on the top of the Front Plate while tightening the Rear Adjustment Dial (turn clockwise to tighten).
- The distance from the top of the eyebrow to the bottom of the Skull Mounting System should be approximately 0.5" - 1" as shown. The bottom of the Rear Pad should rest above nape of the neck.



**TIGHTEN**

(Skull Mounting System Fully Closed)  
TURN DIALS CLOCKWISE TO TIGHTEN



**LOOSEN**

(Skull Mounting System Fully Open)  
TURN DIALS COUNTER-CLOCKWISE TO LOOSEN

## 2 FIT DIAL OPERATION

- Proceed to tighten the front and rear Top Adjustment Dials until the Skull Mounting System fits securely on head. Readjust dials as desired to achieve comfortable fit and positioning.
- Once the front and rear Top Adjustment Dials are set, the Rear Adjustment Dial may need to be tightened again.

## 3 CHINSTRAP OPERATION

- Fasten the Chinstrap Buckle. With both hands, pull the two Rear Head-Loc Sliders on the lower webbing straps toward your chin until snug.
- With both hands, pull the two Front Head-Loc Sliders on the webbing straps that come from the front temples of the Skull Mounting System toward your chin until snug.

