

AMP™ COMMUNICATION HEADSET

CONNECTORIZED DOWNLEAD CABLE

SMAHT ICS U174



Connects AMP Headsets to Push-to-Talks Using U94 Inputs

COLOR



BLACK - 21"

1003276-01-0021



BLACK - 30" 1003276-01-0030



BLACK - 60"

1003276-01-0060

This product is covered by one or more patents. For more information visit www.gentexcorp.com/patents

1004004 REV.C

Copyright © 2025 Gentex Corporation. Ops-Core is a registered trademark of Gentex Corporation or its affiliates. AMP is a trademark of Gentex Corporation or its affiliates.

INSTALLATION

CONNECTING AMP HEADSET DOWNLEAD

Connect the low profile end of the downlead cable to either the left or the right side of the headset (user's preference). The downlead cable will have a triangular (**A**) marking on the Fischer connector.

Fischer Connector End





DISCONNECTING AMP HEADSET DOWNLEAD

Disconnect the downlead cable from the headset by pulling down on the outer sleeve of the connector to unlock it.

NOTE: DO NOT attempt to disconnect the downlead cable by pulling the cable itself.



CABLING OPTIONS



Left Downlead

Connector

Right Downlead Connector =



Connecting to the Intercom System (ICS)

(Left or Right Earcup)

- 1. Connect the downlead cable to either the Left or Right Earcup Connector (Ensure proper key alignment).
- 2. Connect the downlead to the U94 input of the ICS system or PTT.

