



ACH-ARC

ACCESSORY RAIL CONNECTOR



Kit includes (2) ACH-ARC Rails and the following mounting hardware and adapters:

(4) 22mm Ballistic Screws (4) 1st Generation T-Nuts (4) 2nd Generation T-Nuts



(2) Wing-Loc Adapters

(2) Picatinny Adapters

Bungees (Optional):



ACH-ARC KIT

TAN

25-99-301



GREEN

25-99-302



BLACK

25-99-303



ACH-ARC KIT W/ BUNGEEES

TAN

25-99-401



GREEN

25-99-402



BLACK


25-99-403



INSTALLATION INSTRUCTIONS

BUNGEE INSTALLATION *(Bungees optional)*

If optional bungees were purchased, insert the bungee ends into the ACH-ARC's Bungee Retention Slot before assembly.




ACH-ARC ASSEMBLY

Align the ACH-ARC with the existing Chinstrap Holes on your ACH helmet. Use your fingers to loosely assemble the ACH-ARC, Helmet Chinstrap, and hardware by following the diagram. Repeat for opposite side of helmet.

Once all components are loosely assembled, finish by using a screwdriver to tighten all four screws from the outside of the shell, making sure that the ACH-ARCs are securely fastened to the helmet.

NOTE: IF YOU HAVE AN OLDER OPS-CORE CHINSTRAP, PLEASE USE THE 1ST GENERATION T-NUTS. 2ND GENERATION T-NUTS ARE COMPATIBLE WITH NEWER CHINSTRAP.




1st Generation 2nd Generation




ADAPTER INSTRUCTIONS

PICATINNY ADAPTER




Connects devices compatible with 1911 Picatinny Rail


1 Slide Picatinny Adapter to preferred position on the ACH-ARC.



2 Tighten screw to lock the adapter into place.




WING-LOC ADAPTER




Use as a base to mount a variety of headborne accessories

1 Attach desired accessory to Wing-Loc Adapter using the through-holes.



2 Pinch tabs on the Wing-Loc Adapter and slide to preferred position on the ACH-ARC.



OPS-CORE, INC.
Marine Industrial Park
12 Channel Street
Boston, MA 02210

Tel: 617.670.3547
Fax: 617.670.3581

Or visit our website
at www.ops-core.com