

***ops-core***<sup>®</sup>



***Mk1***<sup>™</sup>

PERFORMANCE PROTECTIVE EYEWEAR



# CONTENTS

<b>Introduction</b>	3	<b>Fit Adjustment</b>	10
<b>Eyewear Components</b>	4	<b>Care &amp; Maintenance</b>	12
<b>Lens Replacement</b>	6	<b>Accessories</b>	14
Lens Removal	6	<b>Limited Warranty</b>	16
Lens Installation	8		



***ops-core***<sup>®</sup>



Thank you for your purchase of Ops-Core Mk1 Performance Protective Eyewear. This advanced solution combines over fifty years of Gentex experience in high performance optics production for military aircrew and premium eyewear OEMs with Ops-Core modularity and scalability to deliver the ultimate in eyewear for elite defense, law enforcement, and security personnel. Ops-Core Performance Protective Eyewear will offer UV, Ballistic, High Contrast, Laser Dazzle and Advanced Laser Eye Protection. With proper care and maintenance, the Mk1's advanced optics will consistently deliver their intended high levels of performance and protection in the harshest environments.

# EYEWEAR COMPONENTS

## **Mk1 Performance Protective Eyewear Frames with Gentex® Lenses**

(Tinted lenses shown, included lenses may vary)





**Clear Gentex Replacement Lenses**

(Not included with all models)

**Microfiber Pouch**



# LENS REPLACEMENT

## **WARNING:**

Lenses may only be removed and inserted in specific models by following these directions:

## **LENS REMOVAL**

- 1.** Place index finger of one hand onto the bridge of the frame and place the thumb of same hand on top of the frame as shown.





**2.** Flex nose bridge with index finger towards you while pushing the inside edge of the lens out with the thumb as shown.



**3.** Using your thumb, push the lens out of the lens insert groove.



# LENS REPLACEMENT

(CONTINUED)

## LENS INSTALLATION

**1.** Hold frame and lens as shown and slide the outside edge of the lens into the groove in the lens insert.



**2.** Use your thumbs to apply pressure until the outside edge of the lens snaps into the groove in the lens insert.



**3.** Work your way around the edges until all four corners of the lens are firmly snapped into the frame.



# FIT ADJUSTMENT

## **WARNING:**

Do not attempt on polymer frames.

## **FRAME ADJUSTMENT**

If your Ops-Core Performance Protective Eyewear feels too tight, your primary adjustment should be to the front frame. Hold the frame in both hands and carefully flex the frame outward. Make a number of small adjustments checking each time to see if the desired fit has been achieved. Use caution: Bending the frame too much or too quickly can result in dislodging of lenses or distortion of the frame.



## TEMPLE ADJUSTMENT

If needed, a second adjustment can be made to the narrow end of the eyewear temples. Gently grasp each side temple with one hand and make slight adjustments, checking for desired fit and comfort each time. Make similar adjustments to each side to preserve symmetry.



## CARE & MAINTENANCE

Ops-Core Mk1 Performance Protective Eyewear come with a specially-woven Microfiber Pouch for cleaning and storage. Using the soft bag will help preserve the superior optical quality of your Gentex lenses. Hand wash and air-dry the bag regularly.

When not in use, always carry your eyewear in the provided bag or other sturdy eyewear case. To keep them in shape, use both hands to take them off and avoid putting them face down on a surface – scratches can impede the performance or ruin your lenses.

To avoid scratches, never wipe the lenses when they're dry (there may be dust or particles) and don't use paper towels or other rough materials.

Check your Ops-Core Mk1 Performance Protective Eyewear regularly to make sure the screws aren't loose – if you find one that is, tighten it gently with a small screwdriver.

## Mk1 ACCESSORIES



### **Clear Gentex Lenses**

A14741-1

### **Tint Gentex Lenses**

A14741-2

### **High Contrast Lenses**


A14741-3

### **Dazzle Lenses**

A14741-8

### **Microfiber Bag**

A14746-1







**Standard Inserts**

A14745-1



**Foam Inserts**

A14745-2

# LIMITED WARRANTY

Unless an individual product is covered by a separately issued warranty, Gentex Corporation ("Gentex") warrants that all helmet components, accessories, peripherals, and parts will be free from defects in material or workmanship under normal use and service for a period one (1) year from the date of delivery. All repair covered by this warranty shall be performed at Gentex's factory, or other such warranty repair facilities of Gentex as designated by Gentex unless Gentex specifically directs that repair services be performed at another location. Any defect corrected and found to be within this scope of the warranty will be repaired by Gentex and all charges for labor and material will be borne by Gentex. If it is determined that either no fault exists in Gentex, or the damage to be repaired was caused by negligence of the user, its agents, employees or customers, you agree to pay all charges associated with each such repair. No statement, recommendation or assistance made or offered by Gentex through its representatives to the user, its agents, employees, or customers in connection with the purpose or intended use of any Gentex's product shall be or constitute a waiver by Gentex of any of the provisions of this warranty or change Gentex's liability under this warranty.

EXCEPT WHERE PROHIBITED BY LAW, THE WARRANTY DESCRIBED ABOVE CONSTITUTES THE SOLE WARRANTY MADE BY GENTEX EITHER EXPRESSED OR IMPLIED. THERE ARE NO OTHER WARRANTIES EXPRESSED OR IMPLIED THAT EXTEND BEYOND THE FACE HEREOF, HEREIN, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL GENTEX BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL

DAMAGES EVEN IF ADVISED OF SUCH DAMAGES, AND THE USER, ITS AGENTS, EMPLOYEES, OR CUSTOMERS REMEDIES SHALL BE LIMITED TO SOLELY TO THE REPAIR OR REPLACEMENT OF NONCONFORMING UNITS OR PARTS, WHICH AMOUNT SHALL NOT EXCEED THE TOTAL PURCHASE PRICE OF THE PRODUCT UNDER WARRANTY.

Any tampering, misuse or negligence in handling or use of the product renders the warranty void. Further, the warranty is void if, at any time, the user, its agents, employees or customers attempts to make any internal changes to any of the components of a product; if at any time the power supplied to any part of the product exceeds the rated tolerance; if any external device attached by the user, its agents, employees or customers creates conditions exceeding the tolerance of the product; or if any time the serial number plate is removed or defaced.

OPERATION OF THE PRODUCTS THAT RENDERS THIS WARRANTY VOID WILL BE DEFINED TO INCLUDE ALL OF THE POSSIBILITIES DESCRIBED IN THIS SECTION, TOGETHER WITH ANY PRACTICE THAT RESULTS IN CONDITIONS EXCEEDING THE DESIGN TOLERANCE OF THE PRODUCTS.



***ops-core***<sup>®</sup>

For more information visit [www.ops-core.com](http://www.ops-core.com)

© 2018 Gentex Corporation. Ops-Core and Gentex are registered trademarks of Gentex Corporation or its affiliates.  
Mk1 is a trademark of Gentex Corporation or its affiliates. Certain elements of the product packaging are non-US origin.

TP0413