



UNIVERSAL
NAPE PAD




www.ops-core.com

© OPS-CORE 2018 UM-1036 REV. B

INSTALLATION INSTRUCTIONS

1 REMOVE EXISTING PADS

Remove the rear comfort pad and fitband nape pad as shown.




2 INSTALL UNIVERSAL NAPE PAD

Install the Universal Nape Pad into the helmet starting at the recommended position (see diagram).

The position of the Universal Nape Pad can be adjusted, up or down, depending on the user's preference for both comfort and mobility. Preferred positions can be remembered using the registration marks on the back of the Universal Nape Pad.

NOTE: Lowering the position of the Universal Nape Pad will offer more comfort and nape support but may interfere with certain tasks such as looking up or lying prone.



Recommended Position

Allows for best combination of comfort and mobility.



OPS-CORE, INC.
Marine Industrial Park
12 Channel Street
Boston, MA 02210

Tel: 617.670.3547
Fax: 617.670.3581

Or visit our website
at www.ops-core.com