



RAC HYGIENE KIT

Quick Reference Guide

N993154-00 REV.A



Compatible with Ops-Core RAC Headset

www.ops-core.com

Replacing RAC Hygiene Kit:

1. Pry the old ear seal away from the ear cup by pressing the tab at the bottom.



2. Ensure rubber seal is present and in good condition on the new ear seal.



3. Install the new ear seal, ensuring it is securely snapped to the ear cup around the entire perimeter.

CAUTION: Be careful not to pinch the rubber seal in the groove when snapping the assembly closed.

